Illustrated Parts List Model Series 170700 to 170799

TYPE NUMBERS 2010 through 2040 2111 through 2143 4017 5725 through 5727 6000, 6011, 6012, 6013.


TO FIND THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW


- A. Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number.
- B. Refer to the Illustrations and compare the original part with Illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in assembly frames having individual reference numbers can be purchased separately.
- C. After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE."
- D. If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note."
- E. If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number.
- F. For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply.


PRINTED IN U.S.A.




COPYRIGHT®







8183-4



Reference	Reference No.		310	311	510	544	801	802	803
Starter Motor Mfr.		Motor & Drive Ass'y.	Thru Boly Assembly	Brush Assembly	Drive Assembly	Armature Assembly	End Cap Ass'y Drive	End Cap Ass'y. Commutator	Housing Assembly
Briggs &	Housing			,					-
Stratton	Length_	l						<u> </u>	
12V	3-21/32"	394805	94003	395538	490421**	390837	394856	395537*	398159
United	Housing						1	7	
Technologies	Length							1 1	
12V	3-15/32*	394805		492020	490421**	-	394856	492021	-

*Includes Brush Set

"Includes #398003 Clutch Assembly

(Ref. No. 513)

#280104 Gear

(Ref. No. 783)

#490467 Retainer Kit

(Ref. No. 876)

94192(Black) or 94288(Yellow)Roll Pin (Ref. No. 896)

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	396213	Cylinder Assembly	18	392548	Base-Engine	26	391669	Ring Set-Piston (Std.)
2		Bushing-Cylinder	1	Note:	296594 Base-Engine		391670	Ring Set-Piston
	Note:	Requires Special Tools			Used on Type Nos.			(.010" O.S.)
		For Installation.			2138, 2139.		391671	Ring Set-Piston
3	294606	Seal-Oîl			390479 Base-Engine			(.020" O.S.)
5		Head-Cylinder	}		Used on Type Nos.	4	391672	Ring Set-Piston
6		Washer			2038, 2040.			(.030" O.S.)
7		Gasket-Cylinder Head	19	295963	Bushing-Oil Base	27	68546	Lock-Piston Pin
8		Breather Assembly	1	Note:	Requires Special Tools	28	295840	Pin AssyPiston
	Note:	391406 Breather Assy.			for Installation.			(Standard)
		Used on Type Nos.	20	391086	Seal-Oil		295841	Pin AssyPiston
		5725, 5726, 5727,	21	66768	Plug-Oil Filler	1		(.005" O.S.)
		6013.	22	93585	Screw-Mtg. Sem	29	295839	Rod AssyConnecting
9	±27803	Gasket-Valve Cover	23	298260	Flywheel-Magneto		Note:	For Connecting Rod
10	94621	Screw-Sem	23A	391983	Flywheel and Ring]		With .020" Undersize
11	280005	Tube-Breather			Gear AssyMagneto			Crankpin Bearing-
12	*27750	Gasket-Crankcase	Į.		For Use on Engines	ļ		Order No. 298788.
		Cover (1/64" Thick)	ļ.		WITH ALTERNATOR.	30	221725	Dipper-Connecting Ro
	*27876	Gasket-Crankcase	ł		(Includes Aluminum	31	220811	Lock-Connecting
		Cover (.005" Thick)	ļ		Ring Gear.) For Use			Rod Screw
	*27877	Gasket-Crankcase	1		Only With Starter	32	92659	Screw-Connecting Roo
		Cover (.009" Thick)	1		Motors With Plastic	33	390419	Valve-Exhaust
13	93211	Screw-Cylinder Head	1		Drive Gear.	34	261055	Valve-Intake
		(2-21/32" Long)	1	Note:	392034 Flywheel and	35	65906	Spring-Intake Valve
13A	93776	Stud-Cylinder Head	-		Ring Gear Assy	36	26828	Spring-Exhaust Valve
14	93723	Screw-Cylinder Head	1		Magneto For Use Only	37	222475	Guard-Flywheel
		(3" Long)	ł		on Electric Starter	38	93777	Screw-Sem
	Note:	93781 Stud-Cylinder	ł		Engines	40	221596	Retainer-Intake Valve
		Head (1)			WITHOUT	41	292260	Rotocoil-Exhaust Valve
		22963 Washer (1)			ALTERNATOR	42	93630	Retainer-Exhaust Valv
		Used on Type Nos.	Į		(Includes Aluminum			Rotocoil (2)
		5726, 5727, 6011,			Ring Gear.) For Use	45	260933	Tappet-Valve
		6012.			Only With Starter	46	211689	Gear-Cam
15	91084	Plug-Oil Drain	Į.		Motors With Plastic	52	±270824	Gasket-Carburetor
		93448 Plug-Oil Drain			Drive Gear.			Mounting
		(Hex. Socket)	24	222698	Key-Flywheel	55	393576	Housing-Rewind
16	492476	Crankshaft	25		Piston Assy. (Std.)			Starter
	Note:	Order 94388 Key or			Piston Assembly	56	295871	Pulley-Rewind Starter
		230978 Pin For Loose			(.010" O.S.)		Note:	Includes 63" Rope; if
		Timing Gear Retaining		299567	Piston Assembly			Longer Rope is
		Device.	1		(.020" O.S.)			Required, Order Rope
		492465 Crankshaft		299568	Piston Assembly			No. 66894 and Cut to
		Used on Type Nos.			(.030" O.S.)			Required Length.
		2138, 2139.			, ,	57	490179	Spring-Rewind Starter
		492477 Crankshaft	PISTON	RING SE	rs:	58	66884	Rope-Rewind Starter
		Used on Type Nos.			For Chrome Piston			(63" Long)
		2038, 2040.			Ring Set (Standard			For Use With Plastic
		492525 Crankshaft	1		Size) Order No.			Pulley; if Longer Rope
		Used on Type Nos.			299743.			is Needed, Order No.
		2130, 2131, 2135,	1		-	,		66894 and Cut to
		2142, 5727.						Required Length.
l= -1	dad!- ^- '			-4:- A ·				4
	ded in Gas No. 299577			ed in Carb lo. 394698	uretor Overhaul Kit-			
						i		

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
59	490653	Insert-Starter Handle	121	394698	Carburetor Overhaul Kit	181B	392300	Cap-Fuel Tank
59A	230228	Pin~Starter Grip	123	93357	Screw-Carburetor			(1-9/16" I.D.)
60	490652	Handle-Rewind Starter	1		Mounting			(Metal)
60A	66728	Grip-Starter Rope	125	390811	Carburetor Assembly			(Used Before Code
63	260414	Spring-Ratchet	1		(Choke-A-Matic)			Date 85120100).
64	230543	Adapter-Ratchet	1	Note:	390411 Carb. Assy.	182	222813	Bracket-Fuel Tank,
65	93105	Screw-Rewind	1		(Manual Choke)			R.H.
		Starter Mounting	1		Used on Type Nos.	182A	222112	Bracket-Fuel Tank, L.H.
66	399671	Clutch Assembly-	ł		2010, 2016, 2019, 2111,	183		Strap AssyFuel Tank
		Rewind Starter	1		2112, 2133, 2138,	183A	390405	Strap Assy.~Fuel Tank
67	394897	Housing-Rewind	1		2139, 6000.	184	93803	Screw-Hex. Hd.
		Starter Clutch	126	299851	Body AssyLower	185	90970	Nut-Square
68	63770	Ball-Clutch	1		Carburetor	186	67218	Connector-Fuel Pipe
70	298799	Ratchet-Rewind	127	221997	Plug-Welch	187	296004	Pipe-Fuel
		Starter Clutch	128	211682	Venturi-Carburetor			(Flexible)
71	394506	Washer-Clutch	130	221986	Valve-Throttle			(23" Long)
		Retainer	131	491006	Shaft and Lever-		Note:	393815 Pipe-Fuel
73	221796	Screen-Rewind Starter	1		Throttle			(Flexible)
74	93758	Screw-Sem	132	211712	Stop-Throttle			(11" Long)
75	224061	Washer-Spring	133		Float-Carburetor	188	93535	Screw-Sem
76		Washer-Ratchet	134	•394681	Valve-Fuel Inlet	189	94315	Lock-Washer
		Sealing		Note:	Order 394683 For Fuel	198	293934	Valve~Fuel Shut-Off
78	93805	Screw-Sem			Pump Applications	199	399949	Connector-Fuel Pipe
81	222263	Lock-Screw	136	221995	Bowl-Float		Note:	295896 Connector-
94	•292681	Valve Assembly-	137	•270511	Gasket-Float Bowl			Fuel Pipe
		Carburetor Idle	138	•222014	Washer-Float Bowl			Used on Type Nos.
95	93499	Screw-Throttle and	141	390684	Shaft and Lever Choke			2016, 2017, 2137,
		Choke Valve Mtg. Sem	141A	299647	Shaft and Lever-			2138, 2140.
98	91920	Screw-Machine, Fill.			Manual Choke	200	221760	Guide-Air
		Hd. (5/8" Long)	142	•299740	Nozzle-Carburetor	201	261611	Link-Governor
98A	90200	Screw-Machine, Fill.	147	•231323	Screw-Nozzle			(Used After Code Date
		Hd. (1/2" Long)			(Used After Code Date			82121010).
99	26157	Spring-Throttle			83051900).		Note:	260971 Link-Governor
		Adjustment	1	Note:	230932 Screw-Nozzle	:		(Used Before Code
101	93043	Pin-Throttle Stop			(Used Before Code			Date 82120910).
104	•2308 96	Pin-Float Hinge	l		Date 83052000).	201A	262431	Link-Governor
108	222010	Valve-Choke	169	90832	Washer-Lock			Used on Type Nos.
110	220899	Washer-Choke Lever	171	94314	Nut Hex. Hd.			Above 5999.
111		Spring-Choke Lever	180	390225	Tank AssyFuel	209	261306	Spring-Governor
112		Screw-Choke Lever			(3 Quart)	•		260871 Spring-Gov.
118	•396568	Valve-Needle	ŧ		See Ref. 304 For Fuel			Used on Type Nos.
		(Used After Code Date	į		Tank on Blower			2040, 2133, 2134,
		83051900).	1		Housing.			2135, 2142, 2143,
		includes:	181	493988	Cap-Fuel Tank			5727, 6011, 6012,
		22235 Washer	181A		Cap-Fuel Tank			6013.
		26336 Spring	1	•	(2-1/4" I.D.)			261129 Spring~
		65978 O-Ring	1		(Non-Metal)			Governor
		230590 Nut-Hex.	[(Used After Code Date			Used on Type Nos.
	Note:	396795 Valve-Needle	j		85113100).			2138, 2139.
		(Used Before Code			, .			,
		Date 83052000).	ł					
!= ~!	d=d == ^= :	·		dad := ^-·	vicination Over-transfer			
	ded in Gas No. 299577			no. 394698	uretor Overhaul Kit- I.			
			l			}		

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
216	261612	Link-Choke	268	65616	Casing-Control Wire	305	93158	Screw-Blower Housing
		(Used After Code Date	l		(72" Long)			Mtg. Sem
		82121010).		Note:	If Longer Casing is	306	222830	Shield-Cylinder
Note:	261117 Link-Choke	ļ		Required, Specify	307	93949	Screw-Cylinder Shield	
		(Used Before Code			Length in Inches; if			Mtg. Sem
		Date 82120910).			Shorter Casing is	308	222636	Cover-Cylinder Head
219	491397	Oil Slinger, Governor			Needed, Order No.	309		Motor-Starting
		Gear and Bracket	l		65616 and Cut to			(12 Volt)
		Assembly		•	Required Length.			See Chart on
222	491594	Plate-Governor Control	269	26633	Wire-Control			Illustrated Pages for
		(Used After Code Date			(78" Long)			Starting Motors
		82121010).	1	Note:	If Longer Wire is	l		Replacement Parts.
		396349 Plate-Governor	1		Required, Specify	332	92284	Nut-Flywheel
		Control			Length in Inches; if	333		Armature-Magneto
		(Not Illustrated)	!		Shorter Wire is Needed,	334		Screw-Armature
		(Used Before Code			Order No. 26633 and			Mounting Sem
		Date 82120910).	[Cut to Required Length.	337	298809	Plug-Spark
	Note:	491593 Plate-Governor	270	63426	Locknut-Control			(1-1/2" High, 38 mm.)
		Control	ļ		Wire Casing	1	Note:	293918 Plug-Spark
		(Used After Code Date	271	290568	Lever AssyControl	ļ		(1-1/2" Resistor Type)
		82121010).	284		Screw-Clamp Mtg.			492167 Plug-Spark
		Used on Type Nos.	298		Locknut-Muffler	!		(1-7/8" High)
	2010, 2016, 2019, 2111,	300		Muffler-Exhaust	346	93705	Screw-Hex. Head	
		2112, 2133, 2138,			(Round Lo-Tone)	351		Screw-Terminal
		2139.	300A	398507	Muffler-Exhaust			91920 Screw-Fill. Hd.
225	231058	Crank-Governor	300B		Muffler-Exhaust			Used on Type Nos.
		(1/4" Dia.)	304		Housing-Blower			5725, 5726, 5727.
227	490927	Lever AssyGovenor			299861 Housing-Blow-	352	66068	Washer-Insulating
	10002.	Used on Type Nos.			er	353		LockWasher-Shake-
		Above 4000.			Used on Type Nos.	000	02.01	proof
227A	391733	Lever AssyGovernor			2010, 2019.	354	90576	Nut-Hex. (2)
,		For 1/4" Dia. Crank			491407 Housing-Blow-	355		Collar-Insulating
		Used on Type Nos.			er	356		Wire-Ground
		Below 4000.			Used on Type Nos.	357		Key-Pulley
230	222450	Washer-Governor			6000, 6012.	358		Gasket Set
200		Lever			491408 Housing-Blow-	363		Puller-Flywheel
	•	(1/4" I.D.)			er	373		Nut-Hex.
232	261911	Spring-Gov. Link			Used on Type Nos.	383		Wrench-Spark Plug
ZUL	20.511	(Used After Code Date			5725, 5726, 5727,	422		Clamp-Oil Filler Tube
		82121010).			6011, 6013.	423		Screw-Sem
	Noto	260584 Spring–Gov.			491592 Housing-Blow-	455		Cup-Screen Mounting
	Note.	Link			er er	468		Screen-Flush Rotating
		(Used Before Code			Used on Engines With	474		Stator-Alternator
		Date 82120910).			Electric Starters	7/7	335414	(Dual Circuit)
240	202000	Filter-Fuel			(Ref. No. 309).	482	03631	Screw-Stator Mtg.
240	250050	(In Fuel Line)			491595 Housing-Blow-	517		Pulley-Rope Starter
	Nota	394358 Filter-Fuel			er er	311	20720	(With Screen)
	14016:	(For Fuel Pump			(With 2 Qt. Fuel Tank)	518	60033	Rope-Starter
		•			Used on Type Nos.	520		Terminal-Spade
		Applications.)			2016, 2017, 2137,	520 523		Cap and Dipstick-
248	220240	L'ADDONTAL EURI LIDA '				:1/.5		
244 265		Connector-Fuel Line Clamp-Casing			2138, 2140.	020	051040	Oil Filler

REF.								
NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
524	68838	Seal-Filler Tube		Note:	271013 Washer-	836	93559	Screw-Sem
525	280133	Tube-Oil Filler			Throttle Shaft	842	270920	Seal-Filler Cap
527	221428	Clamp (2)	ĺ		(Used on Engines	847	392066	Filler Group-Oil
534	93323	Screw-Air Cleaner	1		Without Lip Seal-	851	221798	Terminal-Ignition Cable
534A	93622	Screw-Air Cleaner			Ref. 987).	869	211661	Seat-Intake Valve
535	270528	Element-Air Cleaner	635	66538	Elbow-Spark Plug			(Standard)
536	390379	Cleaner AssyAir	643	222149	Cup-Air Cleaner	870	211661	Seat-Exhaust Valve
	Note:	391399 Cleaner Assy	655	222598	Anchor-Spring `			(For Key Retained
		Air	657	93496	Screw-Sem			Gear)
		Uses:	662	222027	Bracket-Carburetor	871	261961	Guide-Exhaust Valve
		280111 Support-Air	663	93572	Screw		Note:	231218 Guide-Intake
		Cleaner Element	670	22963	Spacer-Fuel Tank			Valve
		(Plastic)			(4 Used on Engines			See Repair Manual
		Used on Type Nos.			Without Electric Starter)	877	393456	Diode and Connector
		5725, 5726, 5727.	676	393757	Deflector-Exhaust			Assy
537	270539	Gasket-Air Cleaner	676A	395700	Deflector-Exhaust			(Dual Circuit)
552	491986	Bushing-Governor	683	93572	Screw	877A	393814	Diode and Connector
		Crank	687	390690	Slide-Friction Control			Assy.
		(1/4" I.D.)	688	221766	Cap-Friction Spring	878	393362	Alternator Harness
562	92613	Bolt-Governor Lever	689		Spring-Friction			Assy.
592	231082	Nut-Hex.	690	92484	Screw-Machine, Fil.			(Dual Circuit)
601	93053	Clamp-Fuel Pipe			Head	878A	393422	Harness Assy.
608	390391	Starter AssyRewind	725	223540	Shield-Muffler	883		Gasket-Exhaust
613		Screw-Muffler Mtg.	725A	222175	Shield-Fuel Pipe, Heat	887	391529	Stator Assy.
614		Pin-Cotter	726		Gear-Ring	897		Trigger Coil
615	93307	Retainer-E-Ring			(Aluminum)	917		Valve Handle-Fuel
618		Spring-Choke Return			(Includes Mtg. Parts)			Shut-Off
621		Switch-Stop	727	395405	Cover and Shield-	952	222495	Spacer-Air Cleaner
		(Used After Code Date			Starter	953		Screen-Air Cleaner
		85041400).	728	93523	Screw-Sem	985	398525	Insulator Assembly
	Note:	297472 Switch-Stop	741	262479	Gear-Timing	987		Seal-Throttle Shaft
		(Used Before Code			(For Key Retained			(Carburetor Body Mus
		Date 85041500).			Gear.)			be Cast to Accept)
634	270382	Washer-Choke Shaft		Note:	261195 Gear-Timing	994	399541	Arrester-Spark
634A		Washer-Throttle Shaft			(For Pin Retained	1016	490817	
		(Used on Engines With			Gear.)	1019		Label Kit
		Chrome Throttle Shaft)	763	394952	Electric Starter Kit			
					(12 Volt Gear Drive)			

 Included in Carburetor Overhaul Kit-Part No. 394698.

Included in Gasket Set– Part No. 299577.

